



SECURE THE SOAK PROPERLY. MAKE BETTER LEATHERS.

Remove bacteria from the hide with Busan[®] 1078 to enhance leather quality.

Pre-soaking and soaking can be heavily contaminated with bacteria as ideal conditions for **microbiological growth are present**. And that can lead to downgrading of your leather. To control the bacteria in soaking, Buckman has developed an advanced bactericide to take control of bacteria.

Strong and effective, our Busan 1078 program protects hides from the damage bacteria can do and, just as important, ensures more consistent quality from one batch load to the next. So, you can bring better leathers to market and greater profitability to your leather operation.

PROTECT HIDES FROM BACTERIA. UPGRADE YOUR DEFENSE TODAY!

Busan® 1078 bactericide makes all the difference.

If you see damage in your hides, the cause may be what you can't see—bacteria in the soaking stage. Common problems include:

- Enlargement of the hair follicle
- Accentuation of vein marks
- Loose grain break
- Impaired dyeability
- Reduction in physical properties
- Nubuck effect on grain leather
- Pin prick effect

Fortunately, reducing these problems is easier to resolve with the application of Busan 1078 bactericide in the pre-soak and main soak operations.

Double trouble for bacteria.

Our specially formulated isothiazolinone blend provide dual action: working as a quick kill for immediate bacteria control and as an effective, long-lasting bactericide for continued control during soaking. There's no better way to ensure consistent hide quality.

Easy application and handling.

The amount of Busan 1078 required will vary according to the processing conditions and hides. Most of the time one or multiple dosages ranging from 0.1% to 0.4% on the weight of hides may be used.

The other advantages of Busan 1078 are:

- Diluted liquid formulation for easy and safe handling
- Availability in drums, semi-bulk and bulk containers
- Long storage life—up to a year under normal conditions
- Little or no effect on your biological effluent treatment plant

Learn more.

Secure the quality of your hides during soaking. Contact your Buckman representative or visit buckman.com for more information about advanced Busan 1078 bactericide.

This is not an offer for sale. The product shown in this literature may not be available for sale and/or available in all geographies where Buckman is represented. The claims made may not have been approved for use in all countries. Buckman assumes no obligation or liability for the information. Please contact your Buckman sales representative for more information.

Seller warrants that this product conforms to its chemical description and is reasonably fit for the purpose referred to in the directions for use when used in accordance with the directions under normal conditions. Buyer assumes the risk of any use contrary to such directions. Seller makes no other warranty or representation of any kind, express or implied, concerning the product, including **NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OF THE GOODS FOR ANY OTHER PARTICULAR PURPOSE**. No such warranties shall be implied by law and no agent of seller is authorized to alter this warranty in any way except in writing with a specific reference to this warranty.

Argentina +54 11 4701-6415; Australia +61 (2) 6923 5888; Belgium +32 9 257 92 11; Brasil +55 (19) 3864-5000; Canada +1 (877) 282-5626; Chile +(56-2) 2946-1000; China +(86-21) 6921-0188
India +(91) 44-2648 0220; Indonesia +(62) 21-2988 8288; Korea +(82) 31-416 8991; Mexico +52 (777) 329 3740; Singapore +(65) 6891 9200; South Africa +27 (31) 736 8800; United States +1 (901) 278-0330

Global Headquarters at 1256 N. McLean Blvd., Memphis, TN 38108, USA